



PARTS BREAKDOWN ELECTRIC AIR COMPRESSOR

MODEL:AC3230B



BEPOWEREQUIPMENT


.COM



PARTS BREAKDOWN ELECTRIC AIR COMPRESSOR

MODEL:AC3230B

TANK ASSEMBLY




REF #	DESCRIPTION	QTY	BE PART #
2	Metal Handle	1	42.004.516
46	Handle Screws	2	
47	Foam Handle Grip	1	
11	Bolt	2	42.004.506
12	Wheel	2	
13	Wheel Axel Bolt	2	
14	Tank Drain Valve	1	42.004.012
15	Rubber Foot	2	42.004.505
16	Washer	2	
17	Bolt	2	
29	Tank Check Valve	1	42.004.508
30	Elbow	1	
31	Pipe	1	



PARTS BREAKDOWN ELECTRIC AIR COMPRESSOR


MODEL:AC3230B

PRESSURE SWITCH ASSEMBLY



REF #	DESCRIPTION	QTY	BE PART #
3	Pressure Gauge	1	42.003.006
4	Safety Valve	1	42.010.150
5	Pressure Switch	1	42.004.519
7	Regulator	1	42.004.504
8	Pressure Gauge	1	42.003.005
9	Manifold Fitting	1	42.000.018
9a	Plug	1	
10	Quick Coupler	2	42.000.046

PUMP ASSEMBLY




REF #	DESCRIPTION	QTY	BE PART #
18	Pump Discharge Pipe Assembly	1	42.004.521
19	Pump Assembly (Pulley Included)	1	42.004.510
20	Bolt	4	
21	Washer	4	
22	Hex Nut	4	
23	Oil Plug	1	42.004.523
Not Shown	Air Filter Assembly	1	42.004.524



PARTS BREAKDOWN ELECTRIC AIR COMPRESSOR


MODEL:AC3230B

MOTOR ASSEMBLY



REF #	DESCRIPTION	QTY	BE PART #
28	Motor Bolt	4	42.004.511
27	Washer	4	
26	Hex Nut	4	
50	Cable Gland	1	
23	Motor	1	
25	Allen Head Bolt	1	42.004.512
24	Motor Pulley	1	

BELT GUARD ASSEMBLY




REF #	DESCRIPTION	QTY	BE PART #
35	Belt	1	42.004.513
36-44	Belt Guard Assembly	1	42.004.522
42-45	Belt Guard Support Bracket Assembly	1	42.004.509



PARTS BREAKDOWN ELECTRIC AIR COMPRESSOR

MODEL:AC3230B

COMPLETE ASSEMBLY (REFERENCE ONLY)



BE

POWER EQUIPMENT

If you need technical assistance call:

1-866-850-6662

(8:00am - 4:30pm PST, Mon - Fri)